



SEAT ADJUSTMENT INSTRUCTIONS

- 1.) Have one person hold seat so that there is no tension in cable.
(CAUTION: Remain holding seat while adjusting cable.)
- 2.) With the seat being held, the other person can then loosen and remove the 3/8"X2" bolt using two 9/16" wrenches.
- 3.) To raise the seat, the cable end fitting can be moved to the top hole.
- 4.) To lower the seat, the cable end fitting can be moved to the bottom hole.
- 5.) Be sure to feed bolt through cable end fitting and tighten bolt.

UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES
TOLERANCES ARE:
FRACTIONS DECIMALS ANGLES
±1/16" .XX=±.02 ±1°
.XXX=±.005

REFERENCE CODE

SLCDA

POWER LIFT®

PART NUMBER **80500A**

PART NAME
ASSY, SELECTORIZED, CHIN DIP ASSIST

CAD GENERATED DRAWING
DO NOT MANUALLY UPDATE,

SHEET 6 OF 6	REV. F
SCALE 1:48	SIZE A